



Snow Chain Installation

This Instruction covers most Snow Chains used with Avant Loaders















The looking behind the tyre, unite both ends of the chain, using the connecting hook.













Then pull up the chain, to connect the top of the links, using now the loose c-shape chain links







Connecting both ends of the chain, on the top of the tyre, using the separate c-shape linkage.










....and then also the other one




Luottamuksellinen






Both the c-shape top linkages connected.








Arrange the shackle correctly before tensioning. The threaded hole must remain underneath, so that, in the end it will be easier to close this device.











Here also the shackle has been closed with its threaded pin.







Finally do not forget to tie up the remaining loose chain-links with some cable ties etc.



After the snow-chains have been installed you can insert the air valve and fill up the tyres. After the installation double-check once more, that the wheels can turn freely before starting any actual work.

In some occasions, it is recommendable to use some specific spacers under the rims, to bring the tyres some few millimetres outwards, in order to prevent any rubbing against the covers, or the frame of the loader.



