









## Avant 760i

### Indicator lights on dashboard, additional engine indicator lights

There are additional indicator lights on the dashboard of Avant 760i. The lights are controlled by the Engine Control Unit (ECU). A separate label will be used to explain the indicator lamps.



Label A418499

	Grid heater on	Orange	Indicates that an electric heating element at the engine intake is on. Operation of heater can't be controlled by the operator of the loader. The heater will be active when starting the engine at ambient temperatures below -15°C / 5F.
	Water in fuel	Yellow	Water has been detected in fuel, the water separator must be drained.
	Check Engine	Yellow	The ECU has detected a fault and a diagnostics code is stored in the memory. The code can be read with an OBD-II tool.
	Coolant temperature high	Red	High coolant temperature, remove engine load or shut down the engine and allow to cool. If repeated, find cause for high temperature. Clean the radiator from the fan side.
	Malfunction Indicator Light	Red	The ECU has detected a fault and the engine is set to fault mode (including reduction of engine output). The loader can be driven to a safe location for service. Contact authorized service.
	Oil Pressure Low	Red	Shut down the engine immediately. Low oil pressure can cause severe engine damage.